Motorised VHS-C adapter

General information

This adapter makes it possible to record on or view VHS-C casettes using all VHS videorecorders. The loading and unloading of the tape into and out of the adapter takes place automatically when the shutter is closed and opened. For this purpose, a penlight battery must be inserted.

Sales information

Order code:	**VHS-C ADAPTOR**
Product description:	Motorised VHS-C adapter
Packaging:	Blister
Brand name:	HQ

5 41281 0 022311

Quantity	LxWxH (mm)	Weight
1	140x35x260	261 gr.
15	155x270x460	4160 gr.
30	335x300x485	9400 gr.

Information is subject to change without prior notice. Contents may differ from what is shown. Supplier can not be held responsible, nor liable for the information contained in this document. This document was generated at 06/01/2015 11:09:31